


C115CICE INSTALL GUIDE







Overall Product Dimensions			
Model No.	Height	Width	Depth
C115CICE	32" - 33"	14 3/4"	20"

Cutout Dimensions for Island			
Model No.	Height	Width	Depth
C115CICE	33 1/4"	15"	22 1/4"

Model No.	Rated Voltage	Amps	Hz	Refrigerant	Power Input	Water Pressure	Ice Storage Cap.
C115CICE	115V AC	10	60	R600a/0.67Oz	168 W	19.87- 120.38 PSI	19lbs

Electrical Requirements:

- ✓ This ice maker must be installed in accordance with National Electric Codes, as well as state, municipal and local codes
- ✓ The correct voltage, frequency and amperage must be supplied to the icemaker from a grounded circuit which is protected by a properly sized circuit breaker or time delay fuse.
- ✓ The proper voltage, frequency and amperage ratings are listed on the product rating plate.
- ✓ The ice maker must be properly grounded at all times when electrical power is applied.
- ✓ Use the legs of the unit to properly level it in your cabinet.
- ✓ Never allow any debris to build up underneath, or in front of the unit, blocking ventilation.

Important Note to Installer: *This file is not intended to replace your Owners' Manual which contains specific safety requirements and consumer guidelines. Please refer to your Owners' Manual prior to installing or operating your refrigerator.*

COYOTE
Outdoor Living

www.coyoteoutdoor.com